

Bugh Composite Furniture

Table Assembly Instructions

Parts

Table Top

- (2) Leg assemblies
- (1) Cross brace
- (4) 6" Headlok screws
- (8) 2-7/8" Headlok screws
- (1) Torx driver bit

- 1.) Lay table top down on clean flat surface.
- 2.) Attach two leg assemblies to top with (8) 2-7/8" Headlok screws through predrilled holes. Align with angle block on outside of table supports.
- 3.) Set cross brace on top alignment blocks on inside of leg assemble and attach with (4) 6" Headlok screws through predrilled holes.

NOTE: If your power screw drive cannot set Headlok screw tight, a 1/4" socket can be used with the Torx driver bit.

